



## Cross Reference Guide

### Bevel Seat Fittings

| Top Line | Alfa-Laval | Waukesha | VNE    |
|----------|------------|----------|--------|
| 13H      | 13H        | 13H      | 13H    |
| 2C       | 2C         | 2C       | 2C     |
| 2E       | 2E         | 2E       | 2E     |
| 2F       | 2F         | 2F       | 2F     |
| 2F-31    | 2F-31      | 2F-31    | —      |
| 2K       | 2K         | 2K       | 2K     |
| 2P       | 2P         | 2P       | 2P     |
| 7        | 7          | 7        | 7      |
| 7A       | 7A         | 7A       | 7A     |
| 7B       | 7B         | 7B       | 7B     |
| 14PRF    | 14PRF      | 14W      | 14PR   |
| 14R      | 14R        | 14R      | 14R    |
| L14A7    | L14A7      | 14A      | E614A7 |
| 14W      | 14W        | 14W      | 14W    |
| 14WL     | 14WL       | 14WL     | 14WL   |
| 15TRF    | 15TRFS     | 15W      | 15TR   |
| L15A7    | L15A7      | 15A      | E615A7 |
| 15R      | 15R        | 15R      | 15R    |
| 15W      | 15W        | 15W      | 15W    |
| 15WL     | 15WL       | 15WL     | 15WL   |
| 16A      | 16A        | 16A      | 16A    |
| 31-14F   | 31-14F     | 31-14F   | 31-14F |
| 31-15F   | 31-15F     | 31-15F   | 31-15F |
| 31-18F   | 31-18F     | 22-31F   | —      |
| 31-19F   | 31-19F     | 21-31F   | —      |
| 32-14F   | 32-14F     | 32-14F   | 32-14F |
| 32-15F   | 32-15F     | 32-15F   | 32-15F |
| 31TT     | 31TT       | 31TT     | 31TT   |
| 31TP     | 31TP       | 31TP     | 31TP   |
| 14-18    | 14-18      | 22-14    | 14-18  |
| 14-19    | 14-19      | 21-14    | 14-19  |
| 21       | 21         | 21       | 21     |
| 22       | 22         | 22       | 22     |
| 14AHR    | 14AHR      | 14AHR    | 14AHR  |
| 14AHT    | 14AHT      | 14AHT    | 14AHT  |
| 15AHR    | 15AHR      | 15AHR    | 15AHR  |
| 15AHT    | 15AHT      | 15AHT    | 15AHT  |
| 25H      | 25H        | 25H      | —      |
| 14PRFJFP | 14PRFJFP   | —        | —      |
| L14AJFP  | L14AJFP    | —        | —      |
| 15TRFJFP | 15TRFJFP   | —        | —      |
| L15AJFP  | L15AJFP    | —        | —      |
| 16AJFP   | 16AJFP     | —        | —      |



## Cross Reference Guide

### Clamp Type Fittings

| Top Line  | Alfa-Laval | Waukesha  | VNE     |
|-----------|------------|-----------|---------|
| 2CMP      | B2CMP      | 2CMP      | E62C    |
| 2FMP-14   | 2FMP-14    | 2FMP-14   | E62FPR  |
| 2FMP-15   | 2FMP-15    | 2FMP-15   | E62FTR  |
| 2CMP-31MP | 2CMP-31MP  | 2CMP-31MP | E62C-31 |
| 2FMP-31   | 2FMP-31    | 2FMP-31   | —       |
| 2KMP      | B2KMP      | 2KMP      | E62K    |
| 7MP       | B7MP       | 7MP       | E67     |
| 7RMP      | B7RMP      | 7RMP      | E67R    |
| 9MP       | B9MP       | 9MP       | E69     |
| 23BMP     | 23BMP      | 23BMP     | —       |
| 31RMP     | 31RMP      | 31RMP     | E631R   |
| 32RMP     | 32RMP      | 32RMP     | —       |
| L14AM7    | L14AM7     | L14AM7    | E614AM7 |
| 14RMP     | 14RMP      | 14RMP     | E614R   |
| 14MPW     | 14MPW      | 14MPW     | —       |
| 14WLMP    | 14WLMP     | 14WLMP    | E614WL  |
| 14WMP     | 14WMPS     | 14WMP     | E62CS   |
| 14MPHR    | 14MPHR     | 14MPHR    | E614RT  |
| 14MPHT    | 14MPHT     | 14MPHT    | E614HT  |
| 17MP-14   | 17MP-14    | 17-14MP   | E617PR  |
| 17MP-15   | 17MP-15    | 17-15MP   | E617TR  |
| 21MP      | 21MP       | 21MP      | E621    |
| 22MP      | 22MP       | 22MP      | E622    |
| 31-14MP   | B31-14MP   | 31-14MP   | E631CC  |
| 32-14MP   | B32-14MP   | 32-14MP   | E632CC  |
| 31TMP     | 31TMP      | 31TMP     | E63TTC  |
| 31MPT     | 31MPT      | 31MPT     | E631TC  |
| 31PMP     | 31PMP      | 31PMP     | E631PC  |
| 31MPP     | 31MPP      | 31MPP     | E632CP  |
| 16AMP     | 16AMP      | 16AMP     | E616A   |
| 13MHHM    | 13MHHM     | 13MHHM    | 13MHHM  |
| 13MHLA    | 13MHLA     | K13LH     | E613    |
| 13LAH     | A13MHHM    | —         | —       |



## Cross Reference Guide

### Sanitary Butt Weld Fittings

| Top Line | Alfa-Laval | Waukesha | VNE    |
|----------|------------|----------|--------|
| L2S      | L2S        | 2-CW     | E23    |
| L2KS     | L2KS       | 2-KW     | E2KS   |
| L2CM     | L2CM       | 2CKW     | E2C    |
| L2C      | L2C        | —        | E2T    |
| L2F      | L2F        | —        | E2F    |
| L2P      | L2P        | —        | E2KP   |
| L2K      | L2K        | —        | E2KT   |
| L2KM     | L2KM       | 2KKW     | E2KC   |
| L2CP7    | —          | 2CPW     | —      |
| L7WWW    | L7WWW      | 7W       | E7WWW  |
| L7RWWW   | L7RWWW     | 7WR      | E7RWW  |
| L9WWWW   | L9WWWW     | 9W       | E9WWW  |
| L31      | L31        | 31W      | E31WWW |
| L32      | L32        | 32W      | E32WWW |



## Cross Reference Guide

### Tube OD Fittings

| <b>Top Line</b> | <b>Alfa-Laval</b> | <b>Waukesha</b> | <b>VNE</b> |
|-----------------|-------------------|-----------------|------------|
| 2WCL            | 2WCL              | B2WC            | V2WL       |
| 2WK             | 2WK               | B2WK            | V2WK       |
| 7W              | 7W                | B7W             | V7W        |
| 7WR             | 7WR               | B7WR            | V7WR       |
| 9W              | 9W                | B9W             | V9W        |
| 16W             | 16W               | B16W            | V16W       |
| 19WB            | 19WB              | B19W            | 19WB       |
| 14VB            | 14VB              | B14WA           | —          |
| 31W             | 31W               | B31W            | V31W       |
| 32W             | 32W               | B32W            | V32W       |
| 38SL            | 38SL              | B38W            | —          |